

Checklist for Radon Electret Detector Placement and Retrieval

- Obtain two prepared Electret chambers for each home to be tested
- Ensure closed house conditions are established and discuss with occupant need to maintain it during the testing period
- Open the top of the Electret chamber prior to placement. Record the date and time electret is opened. Date _____ Time _____ Initials _____



OPEN FOR TESTING

- Place the Electret chambers side by side on the placement sheet or at least four inches apart.
 - Place on lowest *occupied* level of the home
 - Do not place in drafts from heating or air conditioning vents
 - Do not place in closets, kitchen, bathroom, laundry room or other closed or high humidity areas (bedrooms are good spot)
 - Place at least 30 inches above the floor
 - Place at least 10 inches from other objects
 - Place at least 30 inches from windows and 10 inches from exterior wall

Retrieval

- Close the tops of the Electret chambers. Record date and time:
Date _____ Time _____ Initials _____



CLOSED AT END OF TEST

- Return Electret chambers and this checklist for voltage reading.
- Acknowledge Receipt of Electret chambers.
Date _____ Time _____ Initials _____